

C&DH


CAUTION
ALARM

Attention Symbol
will appear on
card


User Notification
Attention Symbol,
or call from crew,
or another
console with
funny data

Nominal Config:
Comm Via Early
Comm or OIU

NODE 1 MDM I/O CARD FAILURE PROCEDURE



①
Check with **MCC** to
decide if want to
power cycle the
MDM to try and
regain the I/O card.



②

Before resetting the card, decide if card is supporting more important tasks on any good channel or if need to wait before card reset. This is done via the Node Channelization Chart

③

Check with **MCC** to decide if want to power cycle the MDM to try and regain the I/O card